


REPAINT DOORS WITH AURA® GRAND ENTRANCE



Remove accents.

Protect hardware from drips and leaks.



2 Clean the surface. Remove any loose dirt or mildew.



Scrape and sand away paint. Focus on old drips or chips that make the surface uneven. Sand down the surface with the right grit sandpaper.



Tape off the surface.
Prevent drips and spatters on seams and remaining hardware.



Prime your door.
Use Fresh Start® Primer to create the ideal base surface for the new paint.





Apply the first coat. Cut in nooks and trim with an angled brush. Use a roller for flat surfaces. Let the paint dry for 24 hours.




Sand lightly. Use 220-grit sandpaper to smooth out the surface.





Apply second coat.
Fully cover the door for the best coverage and finish. Let the paint dry for 24 hours.



Reinstall the hardware.





See this and other How-To videos at YouTube.com/BenjaminMoore