

SUPER SPEC® MASONRY INTERIOR/EXTERIOR HI-BUILD BLOCK FILLER K206

Features

- Fills small cracks and voids in concrete, cinder block, and rough masonry
- Can be used with either interior or exterior Benjamin Moore finish coats
- Can be used on exterior masonry surfaces when properly top coated with a Benjamin Moore exterior finish product

General Description

A full bodied and high build, latex block filler specially formulated for easy brush, roll or spray application.

Recommended For

Super Spec[®] Masonry Interior/Exterior, Hi-Build Block Filler (K206) is designed to be used as a preparatory coating to create a less porous, smoother painting surface.

Limitations

- Should not be used as a waterproofing sealer or as a finish coat
- Avoid application to surfaces freshly treated with silicone type water repellents
- Do not apply when air and surface temperature are below 10 °C (50 °F)

Product Inforr	nation		
Colours: — Standard:	Technical Data◊		White
K206 01 White (May be tinted with up to 2.0 fl. oz. of Benjamin Moore® Colour Preview® colorants per 3.79 L.)	Vehicle Type		Acrylic Blended Latex
	Pigment Type		Titanium Dioxide
	Volume Solids		53.4%
— Tint Bases:	Coverage per 3.79L at Recommended Film Thickness		7.0 – 9.3 sq. m. (75 – 100 sq. ft.)
— Special Colours:	Recommended Film Thickness	– Wet – Dry	16 – 21 mils 8.5 – 11.4 mils
Contact your Benjamin Moore representative.	Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure colour uniformity and minimize the disposal of excess paint.		
Certification:	Dry Time @ 25 °C (77 °F) @ 50% RH	To TouchTo Recoat	1 Hour 2 -3 Hours
VOC compliant in all regulated areas.	High humidity and cool temperatures will result in longer dry, recoat and service times.		
CHIP Certified (Collaborative for High Performance Schools) Qualifies for LEED® Credit (INTERIOR NON-FLAT FOR SCHOOLS)	Dries By	Evaporation, Coalescence	
	Viscosity		115 ± 5 KU
	Flash Point		None
	Gloss / Sheen		Flat (10% max.)
	Surface Temperature at Application	– Min.	10 °C (50 °F)
		– Max.	32 °C (90 °F)
	Thin With		N/A
Customer Information Centre: 1-800-361-5898, info@benjaminmoore.ca, www.benjaminmoore.ca	Clean Up Thinner		Clean Water
	Weight Per 3.79L		6.35 kg (14 lbs)
	Storage Temperature	– Min. – Max	4.4 °C (40 °F) 32 °C (90 °F)
	Volatile Organic Compounds (VOC)		
	45 g/L		

♦ Reported values are for White. Contact Benjamin Moore for values of other bases or colours.

Surface Preparation

Surfaces to be painted must be clean and free from wax, oil, grease, and water-soluble materials. Remove all loose mortar, scale, efflorescence and dust. Glossy areas should be dulled. Patch large holes and cracks with a mortar consisting of a 2 to 1 mixture of sand and Portland cement; allow to cure before painting.

Bare masonry surfaces: New masonry must be allowed to cure for 30 days before application of the filler. Remove all loose mortar, scale, efflorescence and dust. Surfaces must be clean and dry.

Mildew: Stains from mildew must be removed by cleaning with Benjamin Moore® Clean (318) prior to coating the surface. **Caution:** Refer to the (318) Clean technical data and material safety data sheets for instructions on its proper use and handling.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ http://www.hc-sc.gc.ca/iyh-vsv/prod/paint-peinture-e.html.

Primer/Finish Systems

For best hiding results, tint Super Spec® Masonry Interior/Exterior, Hi-Build Block Filler (K206) to approximate shade of the finish coat.

Rough or Pitted Masonry (including unglazed brick)

Primer: 1 coat Super Spec[®] Masonry Interior/Exterior, Hi-Build Block Filler (K206)

Finish: 2 coats of the appropriate Benjamin Moore interior or exterior finish.

Application

Stir product thoroughly before use. Apply using airless spray; roller or nylon brush. Typical block filler application is to uniformly spray out the material, then back roll or brush into the surface.

Spray, Airless: Fluid Pressure — 2,000 to 3,000 PSI;

Tip — .017 – .021 Orifice; Filter — none.

Thinning/Cleaning

Super Spec® Masonry Interior/Exterior, Hi-Build Block Filler (K206) should be applied as packaged to preserve the filling, sealing, and high film-build characteristics it has been formulated to provide. If adjustment is necessary due to evaporation, thin sparingly with clean water and mix thoroughly. Do not add other paints or solvents.

Cleanup: Clean brushes, rollers and other painting tools in warm soapy water after use. Spray equipment should be given a final rinse with mineral spirits to prevent rusting.

USE COMPLETELY OR DISPOSE OF PROPERLY. Dry, empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or state-designated environmental agency for local disposal options.

Environmental, Health & Safety Information

Use only in a well ventilated area. Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after handling.

KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING

Refer to Material Safety Data Sheet for additional health and safety information.