

ECO SPEC® WB INTERIOR LATEX FLAT FINISH F373

Features

- Minimal Odor
- Zero VOC's in any base and any color
- Spatter-resistant
- Dries quickly to a beautiful, washable and uniform flat finish
- Quick return to service

General Description

A low odour, zero VOC (Volatile Organic Compounds), 100% acrylic interior latex flat finish that provides high hiding has excellent touch up and a uniform flat finish. Eco Spec® WB Interior Latex Flat Finish is ideally suited for commercial, facility management and residential applications. Eco Spec® WB Interior Latex Flat Finish does not have the odour of conventional paints that contain ingredients known as VOC.

Recommended For

For use on primed or previously painted drywall, masonry, plaster, wood, metal and wallpapered surfaces. Use Eco Spec® WB Interior Latex Primer (F372) as a first coat when a low odour, solvent free primer/finish system is desired.

Limitations

 Do not paint when temperature of air and surface is below 10 °C (50 °F)

Pastel Base

100% Acrylic Latex

Titanium Dioxide

37.2 - 41.8 sq. m.

(400 - 450 sq. ft.)

39%

Product Information Colours — Standard: Technical Data◊ White (01) Vehicle Type Pigment Type (May be tinted with up to 2.0 fl. oz. of Gennex® Waterborne Colorants per 3.79 L.) Volume Solids Coverage per 3.79 L at - Tint Bases: Recommended Film Thickness Benjamin Moore® Gennex® Bases 1X, 2X, 3X, & 4X - Special Colours: Contact your Benjamin Moore representative **Certifications & Qualifications:** VOC compliant in all regulated areas Zero VOC Class A (0-25) over non-combustible surfaces when tested in accordance with ASTM E-84 Master Painters Institute MPI # 53, 53 X-Green™, 143, 143 X-Green™

Benjamin Moore's Green Promise® designation is our company's assurance that this product meets – and often exceeds – rigorous environmental and performance criteria regarding VOCs, emissions, application, washability, scrubbability and packaging, while also delivering the premium levels of performance you expect from Benjamin Moore.

Qualifies for CHPS

low emitting credit

(Collaborative for High Performance Schools)

YFS

	Recommended Film	– Wet	3.8 mils	
	Thickness	– Dry	1.5 mils	
	Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure colour uniformity and minimize the disposal of excess paint.			
	Dry Time @ 25 °C (77 °F) @ 50% RH	– To Touc	ch ½ – 1 Hour	
		– To Reco	oat 1 – 2 Hours	
	Painted surfaces can be washed after two weeks. High humidity and cool temperatures will result in longer dry, recoat and service times.			
	Dries By	Evaporation, Coalescence		
	Viscosity	99 ± 3 KU		
	Flash Point		None	
	Gloss / Sheen		Flat (3 – 7 @ 85°)	
	Surface Temperature	– Min.	10 °C (50 °F)	
	at Application	– Max.	32.2 °C (90 °F)	
	Thin With		See Chart	
	Clean Up Thinner		Clean Water	
	Weight Per 3.79 L		5.2 kg (11.5 lbs)	
	Storage Temperature	– Min.	4.4 °C (40 °F)	
		– Max.	32.2 °C (90 °F)	

This Benjamin Moore product has been tested by independent third parties and meets or exceeds the published chemical restriction and performance criteria of the

Green Seal™ GS-11 2015 standard

Customer Information Centre:

Eligible for

LEED® v4 Credit

YES

1-800-361-5898, info@benjaminmoore.ca, www.benjaminmoore.ca

CDPH v1

Emissions Certified

YFS

Volatile Organic Compounds (VOC)

0 g/L

Zero VOC post tint (any base and any colour)

VOC

(in any colour)

<50 g/L

^⁰Reported values are for Pastel Base. Contact Benjamin Moore for values of other bases or colours.

Surface Preparation

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust.

New plaster or masonry surfaces must be allowed to cure (30 days) before applying base coat. Cured plaster should be hard, have a slight sheen and maximum pH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form release agents and curing compounds. Remove any powder or loose particles before priming.

Difficult Substrates: Benjamin Moore offers a variety of specialty primers for use over difficult substrates such as plaster, bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore retailer can recommend the right problem-solving primer for your special needs.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ https://www.canada.ca/en/healthcanada/services/environmental-workplace-health/environmental-contaminants/lead/lead-information-package-some-commonly-asked-questions-about-lead-human-health.html

Primer/Finish Systems

New surfaces should be fully primed, and previously painted surfaces may be primed or spot primed as necessary. Eco Spec® WB Interior Latex Primer (F372) is the preferred primer in most situations. For best hiding results use Eco Spec® WB Primer tinted to the approximate finish coat colour. **Special Note:** Certain custom Colours require a Deep Colour Base Primer tinted to a special prescription formula to achieve the desired colour. Consult your retailer.

Wood, and engineered wood products:

Primer: Eco Spec[®] WB Interior Latex Primer (F372) or Fresh Start[®] All-Purpose Alkyd Primer (F024)

Finish: 1 or 2 coats Eco Spec® WB Interior Latex Flat Finish (F373)

Bleeding Woods; like Redwood or Cedar:

Primer: Fresh Start® Multi-Purpose Oil Based Primer (F024) or Fresh

Start® High-Hiding All Purpose Primer (K046)

Finish: 1 or 2 coats Eco Spec® WB Interior Latex Flat Finish (F373)

Drywall:

Primer: Eco Spec® WB Interior Latex Primer (F372), Fresh Start® Multi-Purpose Latex Primer (F023) or Fresh Start® High-Hiding All Purpose Primer (K046)

Finish: 1 or 2 coats Eco Spec® WB Interior Latex Flat Finish (F373)

Plaster (Cured):

Primer: Eco Spec® WB Interior Latex Primer (F372) or Fresh Start® High-Hiding All Purpose Primer (K046)

Finish: 1 or 2 coats Eco Spec® WB Interior Latex Flat Finish (F373)

Rough or Pitted Masonry:

Primer: Ultra Spec[®] Masonry Interior/Exterior Hi-Build Block Filler (K571)

Finish: 1 or 2 coats Eco Spec® WB Interior Latex Flat Finish (F373)

Smooth Poured or Pre-cast Concrete:

Primer: Eco Spec® WB Interior Latex Primer (F372) or Fresh Start® Multi-Purpose Latex Primer (F023)

Finish: 1 or 2 coats Eco Spec® WB Interior Latex Flat Finish (F373)

Ferrous Metal (Steel and Iron):

Primer: Ultra Spec® HP Acrylic Metal Primer (FP04) or Super Spec

HP® Alkyd Metal Primer (KP06)

Finish: 1 or 2 coats Eco Spec® WB Interior Latex Flat Finish (F373)

Non-Ferrous Metal (Galvanized & Aluminium)

All new metal surfaces must be thoroughly cleaned with Corotech® Oil & Grease Emulsifier (V600) to remove contaminants. New shiny nonferrous metal surfaces that will be subject to abrasion should be dulled with very fine sandpaper or a synthetic steel wool pad to promote adhesion

Primer: Ultra Spec® HP Acrylic Metal Primer (FP04)

Finish: 1 or 2 coats Eco Spec® WB Interior Latex Flat Finish (F373)

Repaint, All Substrates: Prime bare areas with the primer recommended above for the substrate.

Application

Mixing of Paint: Stir thoroughly before and during use. Apply one or two coats. Use the same brushing techniques as you would for any zero-VOC compliant interior coating. For best results, use a premium Benjamin Moore® custom-blended nylon/polyester brush, premium Benjamin Moore® roller or a similar product. Apply paint generously from unpainted area into wet area. Eco Spec® WB dries faster than other acrylic paints, so avoid lap marks by maintaining a wet edge. Roll out vertical sections in 0.9 to 1.2 m (3' to 4') widths. This product can also be sprayed; refer to the chart below for spray recommendations.

Thinning/Cleaning

Conditioning with Benjamin Moore® K518 Extender may be necessary under certain conditions to adjust open time or spray characteristics. The chart below is for general guidance.			
	Mild conditions	Severe conditions	
	Humid (RH> 50%) with no direct sunlight & with little to no wind	Dry (RH<50%), in direct sunlight, or windy conditions	
Brush: Nylon / Polyester	No thinning	Add K518 Extender	
Roller: Premium Quality		or water: Max of 236 ml (8 fl.	
Spray: Airless Pressure: 1,500 -2,500 psi Tip: 0.013- 0.017	necessary	oz.) to a 3.79 L Never add other paints or solvents	

Clean up: Wash brushes, rollers, and other painting tools in warm soapy water immediately after use. Spray equipment should be given a final rinse with mineral spirits to prevent rusting.

USE COMPLETELY OR DISPOSE OF PROPERLY. Dry, empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or provincial environmental agency on disposal options.

Environmental Health & Safety Information

Use only with adequate ventilation. Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after handling

KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING

Refer to Safety Data Sheet for additional health and safety information.