

MOORESTYLE® INTERIOR ACRYLIC LATEX EGGSHELL FINISH K565

Features

- Excellent hiding
- · Great touch up
- · Spatter resistant
- · Low sheen finish
- Washable
- · Quick dry
- Low odour
- · Easy application
- Soap and water cleanup

General Description

An acrylic blended latex eggshell enamel designed for application to a wide variety of interior surfaces such as trim, walls and ceilings. This highly durable, low sheen finish enamel has excellent hiding and touch up along with easy application and soap and water clean up.

Recommended For

For interior trim, walls and ceilings. Ideal for use on primed or previously painted drywall, masonry, plaster, wood, metal and wallpapered surfaces

Limitations

- · Do not apply when air and surface temperatures are below
- 10 °C (50 °F)

Product Inform		
Colours:—Standard: 565 01 Ultra White (May be tinted with up to 2.0 fl. oz. of Benjamin Moore® Colour Preview® colorants per 3.79L.)	Technical Data <u></u> ◊	Pastel Base
	Vehicle Type	Acrylic Blended Latex
	Pigment Type	Titanium Dioxide
	Volume Solids	31.5%
— Tint Bases: Benjamin Moore® Colour Preview® Bases 1B (Pastel), 2B (Medium), 3B (Deep), 4B (Ultra)	Coverage per 3.79 L at Recommended Film Thickness	37.2 – 41.8 sq. m s (400 – 450 sq. ft.)
	Recommended Film – Wet Thickness – Dry	3.8 mils 1.2 mils
—Special Colours: Contact your Benjamin Moore representative Certification:	Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure colour uniformity and minimize the disposal of excess paint.	
VOC complainant in all regulated areas.	Dry Time @ 25 °C — To T (77 °F) @ 50% RH — To F	
Master Painters Institute MPI # 44	Painted surfaces can be washed after two weeks. High humidity and cool temperatures will result in longer dry, recoat and service times	
	Dries By	Evaporation, Coalescence
Customer Information Centre: 1-800-361-5898, info@benjaminmoore.ca, www.benjaminmoore.ca	Viscosity	97 ± 3 KU
	Flash Point	None
	Gloss / Sheen	Eggshell
	Surface Temperature – Min. at Application – Max	(/
	Thin With	Clean Water
	Clean Up Thinner	Clean Water
	Weight Per 3.79 L	4.9 kg (10.8 lbs)
	Storage Temperature – Min. – Max	- (- /
	Volatile Organic Co	, ,
	144 g	

[♦] Reported values are for Pastel Base. Contact Benjamin Moore for values of other bases or colours.

Surface Preparation

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding

New plaster or masonry surfaces must be allowed to cure (30 days) before applying base coat. Cured plaster should be hard, have a slight sheen and maximum pH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form release agents and curing compounds. Remove any powder or loose particles before priming.

Difficult Substrates: Benjamin Moore offers a variety of specialty primers for use over difficult substrates such as plaster, bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore retailer can recommend the right problemsolving primer for your special needs.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ http://www.hc-sc.gc.ca/iyh-vsv/prod/paint-peinture_e.html.

Primer/Finish Systems

MooreStyle® Interior Acrylic Latex Primer Sealer (K562) is the preferred primer in most situations. For best hiding results use MooreStyle® Interior Acrylic Latex Primer Sealer (K562) tinted to the approximate finish coat colour. Special Note: Certain custom colours require a Deep Colour Base Primer tinted to a special prescription formula to achieve the desired colour. Consult your retailer.

Wood, and engineered wood product

Primer: MooreStyle® Interior Acrylic Latex Primer Sealer (K562)

or Fresh Start® All-Purpose Alkyd Primer (K024)

Finish: 1 or 2 coats MooreStyle® Interior Latex Eggshell Finish

(K565)Drywall

Primer: MooreStyle® Interior Acrylic Latex Primer Sealer (K562) or Fresh Start[®] All-Purpose 100% Acrylic Primer (F/K023)

Finish: 1 or 2 coats MooreStyle® Interior Latex Eggshell Finish

(K565)

Plaster

Primer: Fresh Start® All-Purpose 100% Acrylic Primer (F/K023)

or Fresh Start® 100% Acrylic Superior Primer (K046)

Finish: 1 or 2 coats MooreStyle® Interior Latex Eggshell Finish (K565)

Rough or Pitted Masonry

Primer: Super Spec® Latex Block Filler (K160) or Super Spec®

Masonry Interior/Exterior Hi-Build Block Filler (K206)

Finish: 1 or 2 coats MooreStyle® Interior Latex Eggshell Finish

(K565)

Smooth Poured or Pre-cast Concrete

Primer: Fresh Start® All-Purpose 100% Acrylic Primer (F/K023) or

Fresh Start® 100% Acrylic Superior Primer (K046)

Finish: 1 or 2 coats MooreStyle® Interior Latex Eggshell Finish (K565)

Ferrous Metal (Steel and Iron)

Primer: Super Spec HP[®] Acrylic Metal Primer (KP04), Super Spec HP® Alkyd Metal Primer (KP06) or Fresh Start® Rust Inhibitive Primer (K163)

Finish: 1 or 2 coats MooreStyle® Interior Latex Eggshell Finish (K565)

Repaint, All Substrates: Prime bare areas with the primer recommended for the substrate above.

Application

Mixing of Paint: Stir thoroughly before and during use. Apply one or two coats. Paint Application: For best results, use a premium Benjamin Moore® custom-blended nylon/polyester brush, premium Benjamin Moore® roller, or a similar product. Apply paint generously from unpainted area into wet area. This product can also be sprayed.

Spray, Airless: Fluid Pressure — 1,500 or 2,500 PSI; Tip - .013 - .017 Orifice

Thinning/Cleanup

Thinning is unnecessary, but if required to obtain desired application properties, a small amount of clean water may be added. Never add other paints or solvents.

Wash painting tools in warm soapy water immediately after use. Spray equipment should be given a final rinse with mineral spirits to prevent rusting.

USE COMPLETELY OR DISPOSE OF PROPERLY. Dry, empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or provincial environmental agency on disposal options.

Environmental, Health & Safety Information

Use only in a well ventilated area. Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after

KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING

Refer to Material Safety Data Sheet for additional Health and safety information.