

## Features

- Ideal for wallboard and plaster surfaces
- Forms a moisture vapour barrier and reduces heat loss
- Easy to apply; fast dry for quicker recoat

#### **Recommended For**

- For commercial and residential applications
- For new or previously painted drywall construction, plaster, composition board, non-bleeding woods, and concrete

- Good adhesion
- Perm rating of 0.58 when tested under ASTM D 1653
- Hides well with excellent hold out
- Low VOC

## ULTRA SPEC<sup>®</sup> LATEX VAPOUR BARRIER PRIMER SEALER K573

#### **General Description**

A specially designed interior latex primer sealer that provides a film with low vapour permeability. This fast-drying, nonbreathing primer-sealer acts as a moisture vapour barrier when applied on interior walls and ceilings.

#### Limitations

- Do not apply when air and surface temperatures are below 10 °C (50 °F).
- Do not apply to plaster surfaces that are not fully cured. Full cure typically requires 30 days. Plaster will not cure properly if sealed before full cure.

Product Information	tion			
Colours — Standard: White (00)	Technical Data◊ Whit		White	
	Vehicle Type	Styrene	Butadiene Acrylic	
(May be tinted with up to 60 ml of Benjamin Moore <sup>®</sup> Gennex <sup>®</sup> colorants per 3.79 L.)	Pigment Type	Titanium Dioxide		
	Volume Solids	33.5%		
— Tint Bases: Not available	Coverage per Gallon at37.2 - 41.8 sq. m.Recommended Film Thickness(400 - 450 Sq. Ft.)			
	Recommended Film Thickness	– Wet – Dry	3.8 mils 1.3 mils	
— Special Colours: Contact your Benjamin Moore representative.	the right amount of paint for			
Certifications & Qualifications:	Dry Time @ 25 °C (77 °F) @ 50% RH	– To Touch	1 Hour	
		<ul> <li>– To Recoat</li> </ul>	2 Hours	
VOC compliant in all regulated areas	Painted surfaces can be washed after two weeks. High humidity and cool temperatures will result in longer dry, recoat and service times.			
ASTM D 1653; Water Vapour Permeance - 0.58 perms	Dries By	Evaporation, Coalescence		
Class A (0-25) over non-combustible surfaces when tested in accordance	Viscosity	92 ± 2 KU		
with ASTM E-84 Master Painter Institute MPI # 61	Flash Point None			
	Gloss / Sheen		Flat)	
	Surface Temperature at Application	– Min.	10 °C (50 °F)	
		– Max.	32.2 °C (90 °F)	
	Thin With		Do not thin	
	Clean Up Thinner		Clean Water	
Customer Information Centre: 1-800-361-5898, info@benjaminmoore.ca, www.benjaminmoore.ca	Weight Per 3.79 L		4.9 kg (10.93 lbs)	
	Storage Temperature	– Min.	4.4 °C (40 °F)	
		– Max.	32.2 °C (90 °F)	
	Volatile Organic Compounds (VOC)			
	44 Grams/Litre			

◊ Reported values are for White. Contact Benjamin Moore for values of other bases or colours

### **Surface Preparation**

Surfaces to be primed must be clean, dry, and free of wax, grease, dust, dirt, and mildew. Previously coated surfaces should be sound and tight adhering. All plaster surfaces must be thoroughly cured. Patch all holes and cracks with spackling compound. Apply Ultra Spec<sup>®</sup> Latex Vapour Barrier Primer Sealer (K573) before and after filling nail holes, cracks, and other surface imperfections. Glossy areas should be dulled. Remove all peeling and scaling paint by scraping or use of power equipment.

Poured and pre-cast concrete must be allowed to cure for 30 days; block construction should be allowed to cure for 30 days. All surfaces must be thoroughly brushed with stiff fibre bristles to remove loose particles.

**Difficult Substrates:** Benjamin Moore<sup>®</sup> offers a number of specialty primers for use over difficult substrates such as bleeding woods, grease, crayon markings, hard glossy surfaces, galvanized metal, or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore<sup>®</sup> retailer can recommend the right problem-solving primer for your special needs.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ https://www.canada.ca/en/health-canada/services/environmentalworkplace-health/environmental-contaminants/lead/leadinformation-package-some-commonly-asked-questions-about-leadhuman-health.html

## **Primer/Finish Systems**

For best hiding results, tint Ultra Spec<sup>®</sup> Latex Vapour Barrier Primer Sealer (K573) to the approximate shade of the finish coat, especially when a significant colour change is desired.

#### Wood and engineered wood products:

Primer: Ultra Spec<sup>®</sup> Latex Vapour Barrier Primer Sealer (K573) Finish: Appropriate Benjamin Moore<sup>®</sup> interior finish paint

#### Plaster/Drywall:

**Primer:** Ultra Spec<sup>®</sup> Latex Vapour Barrier Primer Sealer (K573) **Finish:** Appropriate Benjamin Moore<sup>®</sup> interior finish paint

#### **Rough or Pitted Masonry:**

Fill: Ultra Spec<sup>®</sup> Latex Vapour Barrier Primer Sealer (K573) Primer: Ultra Spec<sup>®</sup> Latex Vapour Barrier Primer Sealer (K573) Finish: Appropriate Benjamin Moore<sup>®</sup> interior finish paint

#### Smooth Poured or Precast Concrete:

Primer: Ultra Spec<sup>®</sup> Latex Vapour Barrier Primer Sealer (K573) Finish: Appropriate Benjamin Moore<sup>®</sup> interior finish paint

**Repaint, All Substrates:** Prime bare areas with the primer recommended for the substrate above.

## Application

**Mixing of Paint:** Stir thoroughly before use. Apply one or two coats. For best results, use a Benjamin Moore<sup>®</sup> Professional custom-blended nylon/polyester brush, Benjamin Moore<sup>®</sup> Professional roller, or a similar product. This product can also be sprayed.

Spray, Airless: Fluid Pressure- 1,500 to 3,000 PSI;

Tip — .013–.017 Orifice

## Thinning/Clean up

Thinning is unnecessary and it may reduce the perm rating. Never add other paints or solvents.

Clean brushes, rollers and other painting tools in warm soapy water immediately after use. Spray equipment should be given a final rinse with mineral spirits to prevent rusting or follow provincial/local guidelines on solvent use.

## **Environmental, Health & Safety Information**

Use only in a well ventilated area. Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after handling.

## KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING

# Refer to Safety Data Sheet for additional health and safety information.