

Features

- Innovative and proprietary scuff-resistance formula
- Superior durability
- Washable
- Quick dry
- · Great touch-up
- · Easy application
- Spatter resistant
- Eligible for LEED® v4 credit
- Suitable for use in USDA inspected facilities

General Description

485

A high-performance, one-component latex paint specifically engineered to deliver outstanding performance and protection for the toughest high-traffic areas in busy commercial spaces. This breakthrough product offers superior durability and scuffresistance than traditional high-performance two-component coatings, without the pre-mixing, short pot-life and application difficulties related to similar products. It will retain its high-quality appearance longer with minimal maintenance and repainting required. The beautiful eggshell finish is perfect hallways, fitting rooms and waiting areas.

ULTRA SPEC® SCUFF-X®

INTERIOR EGGSHELL FINISH

Limitations

- Do not apply when air and surface temperatures are below 50 °F (10 °C)
- · Not recommended for floors
- · Interior use only

Recommended For

Ideal for high-traffic areas in commercial spaces such as school hallways, hospital waiting areas, hotels lobbies, gym locker rooms and bathrooms, retail fitting rooms, cafeterias, bathrooms and stairwells. For use on primed or previously painted drywall, plaster, wood, metal and wallpapered surfaces.

Product Information			
Colors — Standard:	Technical Data◊	Pastel Base	
White (01)	Vehicle Type Pro	oprietary Acrylic Copolymer	
— Tint Bases: Benjamin Moore® Gennex® bases 1X, 2X, 3X & 4X	Pigment Type	Titanium Dioxide	
	Volume Solids	40 ± 2%	
— Special Colors: Contact your Benjamin Moore representative	Coverage per Gallon at Recommended Film Thickness	350 - 400 sq. ft.	
		Wet 4.3 mils Drv 1.7 mils	
Certifications & Qualifications: VOC compliant in all regulated areas except for SCAQMD	Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure color uniformity and minimize the disposal of excess paint		
Eligible for LEED® v4 Credit Qualifies for CHPS low emitting credit (Collaborative for High Performance Schools) CDPH v1 Emission Certified Class A (0-25) over non-combustible surfaces when tested in accordance with ASTM E-84 Suitable for use in USDA inspected facilities		To Touch 1 Hour To Recoat 2-3 Hours	
	Painted surfaces can be washed after two weeks. High humidity and cool temperatures will result in longer dry, recoat and service times		
	Dries By	Coalescence	
	Viscosity	97 ± 3 KU	
Anti-microbial - This product contains agents which inhibit the growth of microbes on the surface of this paint film. This product contains antimicrobial additives that inhibit the growth of mold and mildew on the surface of the paint film.	Flash Point	N/A	
	Gloss / Sheen Eggshe	II (15-25 @ 85°) (15 @ 60°)	
	- Carrace Temperature	Min. 50 °F Max 90 °F	
	Thin With	See Chart	
Technical Assistance Available through your local authorized independent Benjamin Moore retailer. For the location of the retailer nearest you, call 1-866-708-9180 or visit www.benjaminmoore.com	Clean Up Thinner	Clean Water	
	Weight Per Gallon	10.63 lbs.	
	Storage Temperature —	Min. 40 °F Max. 90 °F	
	Volatile Organic Compounds (VOC)		
	88.4 Grams/Liter 0.74 Lbs./Gallon		

[♦] Reported values are for Pastel Base. Contact Benjamin Moore for values of other bases or color.

Surface Preparation

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust.

New plaster or masonry surfaces must be allowed to cure 30 days before applying base coat. Cured plaster should be hard, have a slight sheen and maximum PH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form release agents and curing compounds. Remove any powder or loose particles before priming. Wood substrates must be thoroughly dry.

Difficult Substrates: Benjamin Moore offers a variety of specialty primers for use over difficult substrates such as bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore® retailer can recommend the right problem-solving primer for your special needs.

WARNING! If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

Primer/Finish Systems

New surfaces should be fully primed, and previously painted surfaces may be primed or spot primed as necessary. For best hiding results, tint the primer to the approximate shade of the finish coat, especially when a significant color change is desired. **Special Note**: Certain custom colors require a Deep Color Base Primer tinted to a special prescription formula to achieve the desired color. Consult your retailer.

Wood, and engineered wood products:

Primer: Ultra Spec® 500 Interior Latex Primer (N534) or Fresh Start® Multi-Purpose Latex Primer (N023)

Finish: 1 or 2 coats Ultra Spec® SCUFF-X® Interior Eggshell Finish (485)

Bleeding Type Woods, (Redwood and Cedar):

Primer: Fresh Start® Multi-Purpose Oil Based Primer (024)

or 1-2 coats of Fresh Start® High-Hiding All Purpose Primer (046) may be used

Drywall:

Primer: Ultra Spec® 500 Interior Latex Primer (N534)

Finish: 1 or 2 coats Ultra Spec® SCUFF-X® Interior Eggshell Finish (485)

Plaster:

Primer: Fresh Start® High-Hiding All Purpose Primer (046) or Fresh Start®

Multi-Purpose Latex Primer (N023)

Finish: 1 or 2 coats Ultra Spec® SCUFF-X® Interior Eggshell Finish (485)

Rough or Pitted Masonry:

Primer: Ultra Spec® Masonry Interior/Exterior Hi-Build Block Filler (571) Finish: 1 or 2 coats Ultra Spec® SCUFF-X® Interior Eggshell Finish (485)

Smooth Poured or Precast Concrete:

Primer: Ultra Spec® Masonry Interior / Exterior 100% Acrylic Masonry

Sealer (608)

Finish: 1 or 2 coats Ultra Spec® SCUFF-X® Interior Eggshell Finish (485)

Ferrous Metal (Steel and Iron):

Primer: Ultra Spec® HP Acrylic Metal Primer (HP04) or Super Spec HP®

Alkyd Metal Primer (P06)

Finish: 1 or 2 coats Ultra Spec® SCUFF-X® Interior Eggshell Finish (485)

Non-Ferrous Metal (Galvanized & Aluminum): All new metal surfaces must be thoroughly cleaned with Corotech® Oil & Grease Emulsifier (V600) to remove contaminants. New shiny non-ferrous metal surfaces that will be subject to abrasion should be dulled with very fine sandpaper or a synthetic steel wool pad to promote adhesion

Primer: Ultra Spec® HP Acrylic Metal Primer (HP04)

Finish: 1 or 2 coats Ultra Spec® SCUFF-X® Interior Eggshell Finish (485)

Wallpapered Surfaces: Remove wallpaper when possible, followed by thoroughly cleaning the surfaces removing all glue residue. Once the surface has fully dried, sand the surfaces to be painted with 150-180 grit paper. Vinyl wallpapered surfaces tightly adhered may be primed with Fresh Start® High-Hiding All Purpose Primer (046) prior to filling the seams and top coating with Ultra Spec® SCUFF-X®

Repaint, All Substrates: Prime bare areas with the primer recommended for the substrate above.

Application

Stir thoroughly before use. Apply one or two coats. For best results, use a Benjamin Moore® Professional custom-blended nylon/polyester brush, Benjamin Moore® Professional roller, or a similar product. This product can also be sprayed.

Conditioning with Benjamin Moore® 518 Extender may be necessary under certain conditions to adjust open time or spray characteristics. The chart below is for general guidance			
	Mild conditions	Severe conditions	
	Humid (RH> 50%) with no direct sunlight & with little to no wind	Dry (RH<50%), in direct sunlight, or windy conditions	
Brush: Nylon / Polyester		Add 518 Extender or water:	
Roller: Premium Quality 3/8" roller cover	No thinning necessary	Max of 8 fl. oz. to a gallon of paint	
Spray: Airless		Never add other paints or solvents.	

Thinning/Clean Up

Thinning is unnecessary, but if required to obtain desired application properties, a small amount of clean water may be added. Never add other paints or solvents.

Clean up: Use soap and water. Spray equipment should be given a final rinse with mineral spirits to prevent corrosion.

Maintenance: SCUFF-X® needs to fully cure for 2 weeks following application, before applying any cleaning chemicals and liquids. Minimal scuffing and stains can be easily removed by using soap and water. For tougher stains, stronger cleaners may be used with a sponge or rag. Before using a new cleaner for the first time, test its effect on the finish by applying in an inconspicuous area to make sure there's no damage to the paint film.

Environmental Health & Safety Information

Not a hazardous substance or mixture according to the Globally Harmonized System (GHS)

Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after handling. Refer to Safety Data Sheet for additional health and safety information.



WARNING Cancer and Reproductive Harm-

www.P65warnings.ca.gov

This document represents hazards of the product referenced above. Refer to the individual Safety Data Sheet for hazards of the specific product you will be using

KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING

Refer to Safety Data Sheet for additional health and safety information.

Benjamin Moore & Co., 101 Paragon Drive, Montvale, NJ 07645 Tel: (201) 573-9600 Fax: (201)573-9046 www.benjaminmoore.com M72 485 US 071919 Benjamin Moore, Fresh Start, Gennex, Scuff-X, Super Spec HP, Ultra Spec and the triangle "M" symbol are registered trademarks to Benjamin Moore & Co. This product is not endorsed by or a division of CHPS. This product is provided by Benjamin Moore, not CHPS. All other marks are the property of their respective owner. ©2016, 2019 Benjamin Moore & Co.

All rights reserved