



SUPER SPEC[®]

INTERIOR LATEX FLAT FINISH

K275

Features

- Excellent hiding
- Easy application and touch-up
- Decorative and uniform flat finish
- Quick dry
- Spatter resistant
- Soap and water clean-up

Recommended For

For new or previously painted interior wallboard, masonry, and primed or previously painted plaster, wood or metal

General Description

An acrylic blended latex flat enamel designed for application to a wide variety of interior surfaces.

Limitations

- Do not apply when air and surface temperatures are below 10 °C (50 °F)

Product Information

<p>Colours — Standard: White (01)</p> <p>(May be tinted with up to 2.0 fl. oz. of Benjamin Moore[®] Colour Preview[®] colorants per 3.79 L.)</p>	<p>Technical Data[◇]</p>		<p>Pastel Base</p>	
<p>— Tint Bases: Benjamin Moore[®] Colour Preview[®] Bases 1B, 2B, 3B, & 4B</p>	<p>Vehicle Type</p>		<p>Acrylic Blended Latex</p>	
<p>— Special Colours: Contact your Benjamin Moore representative.</p>	<p>Pigment Type</p>		<p>Titanium Dioxide</p>	
<p>Certifications & Qualifications: VOC compliant in all regulated areas</p> <p>Class A (0-25) over non-combustible surfaces when tested in accordance with ASTM E-84</p>	<p>Volume Solids</p>		<p>34%</p>	
	<p>Coverage per 3.79 L at Recommended Film Thickness</p>		<p>37.2 – 41.8 sq. m. (400 – 450 sq. ft.)</p>	
<p>CUSTOMER SERVICE INFORMATION CENTRE: 1-800-361-5898, info@benjaminmoore.ca, www.benjaminmoore.ca</p>	<p>Recommended Film Thickness</p>	<p>– Wet – Dry</p>	<p>3.8 mils 1.2 mils</p>	
	<p>Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure colour uniformity and minimize the disposal of excess paint.</p>			
	<p>Dry Time @ 25 °C (77 °F) @ 50 % RH</p>		<p>– To Touch – To Recoat</p>	<p>1 Hour 2 - 3 Hours</p>
	<p>Painted surfaces can be washed after two weeks. High humidity and cool temperatures will result in longer dry, recoat and service times.</p>			
	<p>Dries By</p>		<p>Coalescence</p>	
	<p>Viscosity</p>		<p>93 ± 3 KU</p>	
	<p>Flash Point</p>		<p>N/A</p>	
	<p>Gloss / Sheen</p>		<p>Flat</p>	
	<p>Surface Temperature at Application</p>		<p>– Min. – Max</p>	<p>10 °C (50 °F) 32 °C (90 °F)</p>
	<p>Thin With</p>		<p>Clean Water</p>	
<p>Clean Up Thinner</p>		<p>Clean Water</p>		
<p>Weight Per 3.79 L</p>		<p>5.1 kg (11.2 lbs)</p>		
<p>Storage Temperature</p>		<p>– Min. – Max</p>	<p>4.4 °C (40 °F) 32 °C (90 °F)</p>	
<p>Volatile Organic Compounds (VOC)</p> <p>46 g/L</p>				

[◇]Reported values are for Pastel Base. Contact Benjamin Moore for values of other bases or colours.

Surface Preparation

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water-soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust.

New plaster or masonry surfaces must be allowed to cure (30 days) before applying base coat. Cured plaster should be hard, have a slight sheen and maximum pH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form release agents and curing compounds. Remove any powder or loose particles before priming.

Difficult Substrates: Benjamin Moore offers a variety of specialty primers for use over difficult substrates such as plaster, bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore retailer can recommend the right problem-solving primer for your special needs.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ <https://www.canada.ca/en/health-canada/services/environmental-workplace-health/environmental-contaminants/lead/lead-information-package-some-commonly-asked-questions-about-lead-human-health.html>

Primer/Finish Systems

Super Spec® Latex Enamel Undercoater & Primer Sealer (K253) is the preferred primer in most situations. For best hiding results use Super Spec® Primer tinted to the approximate finish coat colour. **Special Note:** Certain custom colours require a Deep Colour Base Primer tinted to a special prescription formula to achieve the desired colour. Consult your retailer.

Wood and engineered wood products

Primer: Super Spec® Latex Enamel Undercoater & Primer Sealer (K253) or Fresh Start® All-Purpose Alkyd Primer (F024)
Finish: 1 or 2 coats Super Spec® Interior Latex Flat Finish (K275)

Drywall

Primer: Super Spec® Latex Enamel Undercoater & Primer Sealer (K253) or Fresh Start® Multi-Purpose Latex Primer (F023)
Finish: 1 or 2 coats Super Spec® Interior Latex Flat Finish (K275)

Plaster

Primer: Super Spec® Latex Enamel Undercoater & Primer Sealer (K253) or Fresh Start® Multi-Purpose Latex Primer (F023)
Finish: 1 or 2 coats Super Spec® Interior Latex Flat Finish (K275)

Rough or Pitted Masonry

Primer: Ultra Spec® Masonry Interior/Exterior Hi-Build Block Filler (K571)
Finish: 1 or 2 coats Super Spec® Interior Latex Flat Finish (K275)

Smooth Poured or Pre-cast Concrete

Primer: Fresh Start® Multi-Purpose Latex Primer (F023)
Finish: 1 or 2 coats Super Spec® Interior Latex Flat Finish (K275)

Ferrous Metal (Steel and Iron)

Primer: Ultra Spec® HP Acrylic Metal Primer (FP04) or Super Spec HP® Alkyd Metal Primer (KP06)
Finish: 1 or 2 coats Super Spec® Interior Latex Flat Finish (K275).

Non-Ferrous Metal (Galvanized & Aluminium) All new metal surfaces must be thoroughly cleaned with Corotech® Oil & Grease Emulsifier (V600) to remove contaminants. New shiny non-ferrous metal surfaces that will be subject to abrasion should be dulled with very fine sandpaper or a synthetic steel wool pad to promote adhesion.

Primer: Ultra Spec® HP Acrylic Metal Primer (FP04)
Finish: 1 or 2 coats Super Spec® Interior Latex Flat Finish (K275).

Repaint, All Substrates: Prime bare areas with the primer recommended for the substrate above.

Application

Mixing of Paint: Stir thoroughly before and during use. Apply one or two coats. **Paint Application:** For best results, use a premium Benjamin Moore® custom-blended nylon/polyester brush, premium Benjamin Moore® roller, or a similar product. Apply paint generously from unpainted area into wet area. This product can also be sprayed.

Spray, Airless: Fluid Pressure: 1,500 – 2,500 psi;
Tip: 0.013 – 0.017 Orifice

Thinning/Clean Up

Thinning is unnecessary, but if required to obtain desired application properties, a small amount of clean water may be added. Never add other paints or solvents.

Clean up: Wash painting tools in warm soapy water immediately after use. Spray equipment should be given a final rinse with mineral spirits to prevent rusting.

USE COMPLETELY OR DISPOSE OF PROPERLY. Dry empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or provincial environmental agency on disposal options.

Environmental Health & Safety Information

Use only in a well ventilated area. Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after handling.

**KEEP OUT OF REACH OF CHILDREN
PROTECT FROM FREEZING**

**Refer to Material Safety Data Sheet for
additional health and safety information.**