

#### Features

- Provides a total latex system, offering excellent resistance to blistering.
- All season primer.
- Low temperature 2 °C (35 °F) application.
- Easy to apply.
- Excellent hiding and levelling properties.
- Fast dry.
- Low VOC

# Recommended For

- For commercial and residential applications
- Use on both bare and previously coated siding and trim. Ideal for exterior surfaces such as new or previously painted exterior wood, hardboard siding, cured masonry, aluminum and galvanized metal, and unglazed brick.

## Limitations

 Do not apply when air and surface temperatures are below 2 °C (35 °F).

Product Information		
Colours — Standard:	Technical Data White	
K558 00 White (May be tinted with up to 60 ml of Benjamin Moore <sup>®</sup> Gennex <sup>®</sup> colorants per 3.79 L.)	Vehicle Type Acrylic Blended Late	
	Pigment Type Titanium Dioxid	
	Volume Solids 379	
— Tint Bases: Not available	Coverage per 3.79 L at37.2-41.8 sq. rRecommended Film Thickness(400 - 450 Sq. Ft	
— Special Colours:	Recommended Film– Wet3.7 milThickness– Dry1.4 mil	
Contact your Benjamin Moore representative.	Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure colour uniformity and minimize the disposal of	
Certification:	excess paint.	
VOC compliant in all regulated areas	Dry Time @ 25 °C – To Touch 1 Hou   (77 °F) @ 50% RH – To Recoat 3 Hour	
Master Painters Institute MPI #6	Painted surfaces can be washed after two weeks. Hig humidity and cool temperatures will result in longer dry recoat and service times.	
	Dries By Evaporation, Coalescenc	
	Viscosity 89 ± 3 KI	
	Flash Point Non	
Test wind Anniatory	Gloss / Sheen Fla	
<b>Technical Assistance:</b> Available through your local authorized independent Benjamin Moore retailer. For the location of the retailer nearest you, call 1-800-361-5898, info@benjaminmoore.ca, www.benjaminmoore.ca.	Surface Temperature- Min.2 °C (35 °Fat Application- Max32.2 °C (90 °F	
	Thin With Clean Wate	
	Clean Up Thinner Clean Wate	
	Weight Per 3.79 L 5.1 kg (11.3 lbs	
	Storage Temperature – Min. 4.4 °C (40 °F   – Max 32.2 °C (90 °F	
	Volatile Organic Compounds (VOC)	
	45 Grams/Litre	

◊ Reported values are for White. Contact Benjamin Moore for values of other bases or colours

# ULTRA SPEC<sup>®</sup> EXT LATEX PRIMER K558

## **General Description**

An acrylic blended latex primer intended for use under latex exterior house paints to provide a total breathable system.

#### Surface Preparation

Surfaces must be clean, and free of dirt, mildew, grease, excess chalk, and loose or scaling paint. Remove all scaling or peeling paint by scraping, wire brushing or sanding. Glossy areas should be dulled. Loose, sandy masonry and stucco should be dry-brushed down to a firm surface. Spot prime all nail holes and areas before and after using putty or caulking.

Note: Smooth-planed clapboards or siding must be sanded with 80-120 grit sandpaper to break the "mill glaze" and allow proper penetration and adhesion.

Mildew: Stains from mildew must be removed by cleaning with Benjamin Moore<sup>®</sup> Clean (K318) prior to coating the surface. Caution: Refer to the (K318) Clean technical data and material safety data sheets for instructions on its proper use and handling.

Un-weathered areas such as eaves, ceilings or overhangs should be washed with a detergent and/or rinsed with a strong stream from a garden hose to remove surface salts that can interfere with proper adhesion.

For metal surfaces, remove all rust and surface oils. When dry, prime galvanized or aluminum metal surfaces with Ultra Spec® HP D.T.M. Acrylic Metal Primer HP04. For other metal surfaces, prime with the recommended Benjamin Moore® metal primer.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ http://www.hcsc.qc.ca/iyh-vsv/prod/paint-peinture e.html.

### **Primer/Finish Systems**

Spot prime exposed nail holes and areas where paint was scraped down to the bare substrate. Spot prime before and after repairing with caulks and putty.

For best hiding results, tint Ultra Spec® EXT Latex Primer to the approximate shade of the finish coat. Special Note: Certain custom colours require a Deep Colour Base Primer tinted to a special prescription formula to achieve the desired colour. Consult your retailer.

Benjamin Moore offers a number of specialty primers for use over difficult substrates such as bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal, or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore retailer can recommend the right problem-solving primer for your special needs.

#### Wood, New, Non-Bleeding:

Primer: Spot prime joints, cracks or rough spots with Ultra Spec® EXT Latex Primer (K558). Let dry at least 3 hours before applying overall coat of Ultra Spec® EXT Latex Primer K558 Finish: Appropriate Benjamin Moore exterior paint

#### Wood, Repaint (Including Shakes and Shingles):

Primer: Spot prime as needed with Ultra Spec® EXT Latex Primer (K558)

Finish: Appropriate Benjamin Moore exterior paint

#### Hardboard Siding, Factory Primed:

Primer: Ultra Spec® EXT Latex Primer (K558).

Finish: Appropriate Benjamin Moore exterior paint

#### **Rough or Pitted Masonry:**

Primer: Ultra Spec® Hi-Build Masonry Block Filler (K571) Finish: Appropriate Benjamin Moore exterior paint

#### Smooth Poured or Pre-cast Concrete:

Primer: Ultra Spec® EXT Latex Primer (K558). Finish: Appropriate Benjamin Moore exterior paint

#### Masonry, Weathered and Unpainted (Including Unglazed Brick):

Primer: Not required if surface is firm. Loose, sandy masonry should be hosed down thoroughly to remove surface particles, allowed to dry, and then primed with Ultra Spec® Masonry Interior/Exterior 100% Acrylic Sealer (K608). Finish: Appropriate Benjamin Moore exterior paint

Repaint, All Substrates: Prime bare areas with the primer recommended for the substrate above.

#### Application

Stir thoroughly before use. Apply 1 or 2 full even coats by brush, roller or spray gun.

Do not add other paints or solvents.

Spray, Airless: Fluid Pressure- 1,500 to 3,000 PSI; Tip — .013-.017 Orifice

## Thinning/Clean up

Thinning is unnecessary, but if required to obtain desired application properties, a small amount of clean water may be added. Never add other paints or solvents.

Clean brushes, rollers and other painting tools in warm soapy water after use. Spray equipment should be given a final rinse with mineral spirits to prevent rusting.

USE COMPLETELY OR DISPOSE OF PROPERLY, Drv. empty containers may be recycled in a can-recycling program. Local disposal requirements vary; consult your sanitation department or provincial-designated environmental agency on disposal options.

## Environmental, Health & Safety Information

Use only with adequate ventilation. Do not breathe spray mist or sanding dust. Avoid contact with eyes and prolonged or repeated contact with skin. Wear eye protection and gloves during application or sanding. A dust/particulate respirator approved by NIOSH should be worn when sanding or spraying. Close container after each use.

FIRST AID: If you experience difficulty in breathing, leave the area to obtain fresh air.

IN CASE OF SPILL: - Absorb with inert material and dispose of as specified under Thinning/Clean up.

## **KEEP OUT OF REACH OF CHILDREN**

## Refer to Safety Data Sheet for additional health and safety information.

Benjamin Moore & Co., Ltd. 8775 Keele St., Concord, ON L4K 2N1 1-800-361-5898 www.benjaminmoore.ca M72 K558 CE 040716 Benjamin Moore, Gennex, Super Spec, Ultra Spec and the triangle "M" symbol are registered trademarks of Benjamin Moore & Co., Limited. © 2016 Beniamin Moore & Co., Ltd.