

#### Features

- Provides protection and colour without obscuring the grain or texture of the wood
- The semi-solid opacity of this product makes it ideal for reducing colour variations in wood without completely obscuring the wood grain
- Provides mildew resistant coating
- Scuff resistant
- May be applied to new, pressure treated lumber. Ideal for softwoods like cedar and pine.
- Formulated to penetrate, protect, and beautify wooden decking and furniture
- A water repellent coating

#### **Recommended For**

Residential or commercial applications where a premium quality finish is desired. For exterior use on wood decking, fencing, siding, shakes, and furniture.

## ARBORCOAT<sup>®</sup> WATERBORNE EXTERIOR STAIN SEMI-SOLID K639

#### **General Description**

A premium quality 100% acrylic semi-solid stain formulated to penetrate and protect wood, resist abrasion, and beautify wood decking, siding, fencing, shakes and furniture. Its colours are semi-solid, allowing some of the colour and the grain pattern of the wood to show through. Arborcoat<sup>®</sup> Semi-Solid stain can be top coated with Arborcoat<sup>®</sup> Waterborne Protective Clear Coat (K636) for a low lustre look.

#### Limitations

- Do not apply when air and surface temperatures are below 4.4 °C (40 °F)
- Moisture level of wood substrate must be below 15%. Test light colours for tannin bleed over a small area before proceeding
- Not recommended for hardwood
- For a low lustre look, apply a single thin topcoat of Arborcoat<sup>®</sup> Waterborne Protective Clear Coat (K636)

Product Information				
Colours — Standard:	Technical Data◊		White Base	
None	Vehicle Type		100% Acrylic Latex	
	Pigment Type		Titanium Dioxide	
— Tint Bases:	Volume Solids		36%	
White Base (01), Clear Tint Base (06) Tint with Benjamin Moore <sup>®</sup> Gennex <sup>®</sup> Colorants Only	Coverage per 3.79 L at Recommended Film Thi		27.9 – 37.2 sq. m. (300 – 400 sq. ft.)	
	Recommended Film	– Wet	3.5 - 4.8 mils	
— Special Colours:	Thickness	– Dry	1.3 – 1.7 mils	
Contact your Benjamin Moore representative.	Depending on surface texture and porosity. Be sure to estimate the right amount of stain for the job. This will ensure colour uniformity and minimize the disposal of excess material.			
VOC compliant in Canada (77 °F) @ High humic recoat and	Dry Time @ 25 °C	- To Touch	½ Hour	
	(77 °F) @ 50% RH _	- To Recoat	4 Hours	
	recoat and service time	High humidity and cool temperatures will result in longer dry, recoat and service times. Allow 48 hours dry time before subjecting decks to normal foot traffic.		
	Viscosity		72 ± 3 KU	
	Flash Point		None	
CUSTOMER SERVICE INFORMATION CENTRE	Gloss / Sheen		Flat	
1-800-361-5898, info@benjaminmoore.ca, www.benjaminmoore.ca	Surface Temperature	– Min.	4.4 °C (40 °F)	
www.benjuminineore.eu	at Application	– Max.	32.2 °C (90 °F)	
	Thin With		See Chart	
	Clean Up Thinner		Clean Water	
	Weight Per 3.79 L		4.67 kg (10.3 lbs)	
	Storage Temperature	– Min.	4.4 °C (40 °F)	
		– Max	32.2 °C (90 °F)	
	Volatile Organic Compounds (VOC)			
	93 g/L			

◊Reported values are for colour shown. Contact Benjamin Moore for values of other bases or colours.

#### Arborcoat<sup>®</sup> Exterior Waterborne Semi-Solid Deck & Siding Stain K639

#### **Surface Preparation**

Optimal performance is achieved when the product is applied to a clean, dry and absorbent wood substrate. This product must be able to penetrate.

**New Wood:** Smooth planed wood siding, trim, or deck boards must be sanded thoroughly or treated with Benjamin Moore<sup>®</sup> Brighten, Brightener & Neutralizer (K317) to break the "mill glaze" and allow proper penetration and adhesion. After prep is complete, test for penetration by applying a few drops of water to the dry substrate. If the water does not quickly penetrate, repeat prep or consult your Benjamin Moore<sup>®</sup> retailer.

**Weathered Wood:** Prior to staining, weathered wood must be treated with Benjamin Moore<sup>®</sup> Restore, for Gray & Weathered Wood (K316), following label directions, until a sound surface is obtained (loose or damaged wood fibers removed).

**Previously Stained Surfaces:** This product can also be applied to surfaces previously stained with a transparent stain that is weathered but is not flaking or peeling. Remove contaminants or chalky residue from weathered stained surfaces by washing with Benjamin Moore<sup>®</sup> Clean, Multi-Purpose Cleaner (K318) and allow to dry thoroughly.

If the existing stain is flaking or peeling it should be removed prior to staining. Existing paint, stain or sealer can be removed by sanding with an On Floor machine or using Benjamin Moore<sup>®</sup> Remove, Finish Remover (K315).

**Un-weathered areas** such as eaves, ceilings, overhangs or protected wall areas must be washed with Benjamin Moore<sup>®</sup> Clean, Multi-Purpose Cleaner (K318) and rinsed with a strong stream from a garden hose to remove surface salts that can interfere with proper adhesion.

**Mildew:** Stains from mildew must be removed by cleaning with Benjamin Moore<sup>®</sup> Clean (K318) prior to coating the surface.

**Caution:** Refer to the K315, K316, K317 and K318 technical data and safety data sheets for instructions on their proper use and handling.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ https://www.canada.ca/en/health-canada/services/environmentalworkplace-health/environmental-contaminants/lead/lead-informationpackage-some-commonly-asked-questions-about-lead-human-

health.html

#### Application

Prior to finishing, ensure having enough stain to complete an entire section.

Stir thoroughly before and occasionally during use. Stain can be applied by brush, roller, pad applicator or by spray. If the product is applied using a roller or sprayer, it is recommended to back-brush the stain into the wood with the direction of the natural grain. Apply as received in the container.

Apply 1 or 2 coats Arborcoat<sup>®</sup> Waterborne Exterior Stain. A second coat provides optimal performance and uniformity. Wait for the first coat to dry for a minimum of 4 hours before applying the second coat. Please note that multiple coats will affect the opacity of the final finish and obscure more of the natural colour of the wood

#### In can colour may differ from the final dried finish.

Start by coating a sample of the exact wood you intend to finish. The finished colour and sheen of the stain system can vary depending on the type of wood—its natural colour, texture, grain porosity, and section of log from which it was cut.

Apply evenly, allowing the stain to penetrate into the wood. Brush from dry into wet areas, stopping at natural breaks, i.e. stairs or edges. To minimize lapping, always maintain a wet edge. On horizontal siding apply the stain on a section of 2 or 3 boards completely across the house. Lower the ladder and continue in the same manner until the side is completed. Vertical siding is coated using the same principle from top to bottom. Never stop staining in mid-wall; continue until a natural break is reached, such as a window.

Do not apply excess amounts as this will prevent optimum cure and may result in a solid colour appearance. Do not apply in direct sunlight as this will prevent the product from penetrating properly, causing lap marks.

#### **Thinning/Cleanup**

Conditioning with Benjamin Moore <sup>®</sup> K518 Extender may be necessary under certain conditions to adjust open time or spray characteristics. The chart below is for general guidance				
	Mild conditions	Severe conditions		
	Humid (RH> 50%) with no direct sunlight & with little to no wind	Dry (RH<50%), in direct sunlight, or windy conditions		
Brush: Nylon / Polyester		Add K518 Extender		
Roller: Premium Quality Nylon/Polyester	No thinning necessary	or <b>water:</b> Max of 236 ml (8 fl. oz.) to a 3.79 L		
<b>Spray: Airless</b> Pressure: 1200 -1800 psi Tip: 0.011-0.015		Never add other paints or solvents.		

Use soap and water.

USE COMPLETELY OR DISPOSE OF PROPERLY. Dry empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or provincial environmental agency on disposal options.

#### **Environmental, Health & Safety Information**

Use only in a well ventilated area. Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after handling.

### KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING

# Refer to Safety Data Sheet for additional health and safety information.

Benjamin Moore & Co., Ltd. 8775 Keele St., Concord, ON L4K 2N1 1-800-361-5898 www.benjaminmoore.ca M72 K639 CE 091318 Arborcoat, Benjamin Moore, Gennex, and the triangle "M" symbol are registered trademarks of Benjamin Moore & Co., Ltd. © 2009, 2018 Benjamin Moore & Co., Ltd.