

ADVANCE® WATERBORNE INTERIOR ALKYD SATIN 792

Features

- · Excellent durability
- Excellent flow and leveling properties
- Extended open time
- Minimal yellowing
- Spatter resistant
- · Easy application
- Easy clean up
- Block resistant

General Description

A premium quality, waterborne alkyd enamel that delivers the desired flow and leveling characteristics of conventional alkyd paint. It provides a tough, satin finish that stands up to repeated washing. It is easy to apply, resists spattering and cleans up with soap and water.

Recommended For

Ideal for interior doors, trim, cabinets, walls, and ceilings. For primed or previously painted wallboard, plaster, masonry, wood and metal.

Limitations

- Depending on weather and drying conditions, it could take up to 30 days to reach optimum hardness and final sheen.
- · Sand glossy alkyds before applying Advance

| Product Inform | ation | | |
|--|---|--|-----------------------|
| Colors — Standard: | Technical Data◊ | | Pastel Base |
| White (01), Black (80) | Vehicle Type | | Waterborne alkyd |
| | Pigment Type | | Titanium Dioxide |
| — Tint Bases: | Volume Solids | | 39% |
| Benjamin Moore® Gennex® Bases 1X, 2X, 3X, 4X | Coverage per Gallon at Recommended Film Thio | ckness | 400 – 500 sq. ft. |
| — Special Colors: Contact your Benjamin Moore representative. | Recommended Film | – Wet | 3.6 mils |
| | Thickness | – Dry | 1.35 mils |
| Certifications & Qualifications: | Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure color uniformity and minimize the disposal of excess paint. | | |
| Qualifies for LEED® v4 Credit Qualifies for CHPS low emitting credit (Collaborative for High Performance Schools) CDPH v1 Emission Certified Class A (0-25) over non-combustible surfaces when tested in accordance with ASTM E-84 Water Vapor Transmission: ASTM D1653 (method A): 2.55 perms | Dry Time @ 77 °F (25 °C) @ 50% RH | To TouchTo Recoat | 4-6 Hours 16 Hours |
| | Advance's full hardness and adhesion develop over time. Do not expose to heavy abrasion or return shelves/tabletops to service for at least 5-7 days to prevent damage to the finish. High humidity or cooler temperatures will prolong dry, recoat and cure times. | | |
| | Dries By | Evaporation, Oxidation | |
| | Viscosity | | 95 ± 5 KU |
| | Flash Point | | None |
| | Gloss / Sheen | S | atin (25 - 35 @ 60°) |
| Technical Assistance | Surface Temperature at Application | – Min. | 50 °F |
| Available through your local authorized independent Benjamin Moore retailer. For the location of the retailer nearest you, call 1-866-708-9180 or visit www.benjaminmoore.com | | – Max | 90 °F |
| | Thin With | | Clean Water |
| | Clean Up Thinner | | Clean Water |
| | Weight Per Gallon | | 10.9 lbs. |
| | Storage Temperature | – Min | 40 °F |
| | | – Max | 90 °F |
| | Volatile Organic Compounds (VOC) 48 Grams/Liter 0.40 Lbs./Gallon | | |
| | | | |

 $\Diamond \mbox{Reported}$ values are for Pastel Base. Contact Benjamin Moore for values of other bases or colors

Surface Preparation

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free

New plaster or masonry surfaces must be allowed to cure before applying base coat. Cured plaster should be hard, have a slight sheen and maximum PH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form release agents and curing compounds. Remove any powder or loose particles before priming. Wood substrates must be thoroughly dry.

Difficult Substrates: Benjamin Moore offers a number of specialty primers for use over difficult substrates such as bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal, or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore® retailer can recommend the right problem solving primer for your special

Note: Although Advance yellows less than conventional alkyds, a slight amount of yellowing may occur. This effect is accelerated in dark or poorly ventilated areas and is more visible in lighter colors.

WARNING! If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSHapproved respirator to control lead exposure. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

Primer/Finish Systems

New surfaces should be fully primed, and previously painted surfaces may be primed or spot primed as necessary. For best hiding results use Benjamin Moore® Advance Waterborne Interior Alkyd Primer tinted to the approximate finish coat color. Special Note: Certain custom colors require a Deep Color Base Primer tinted to a special prescription formula to achieve the desired color. Consult your retailer.

Wood and Engineered Wood Products:

Primer: Advance® Waterborne Interior Alkyd Primer (790), Fresh Start® High-Hiding All Purpose Primer (046) or Fresh Start® Multi-Purpose Oil Based Primer (024)

Finish: 1 or 2 coats Advance® Waterborne Interior Alkyd Satin (792)

Cabinetry - All surfaces to be roughened by sanding (220 grit or coarser) before priming; light sanding between coats allows for a smoother finish; all dust must be cleaned.

Wood, MDF & Thermofoil

Primer: 1 coat Advance® Waterborne Interior Alkyd Primer (790)
Finish: 1 or more coats of Advance® Waterborne Interior Alkyd Satin (792)

Laminate (Formica)

Primer: 1 coat Fresh Start® High-Hiding All Purpose Primer (046)
Finish: 1 or more coats of Advance® Waterborne Interior Alkyd Satin (792)

Plastic (Vinyl) Veneer

Primer: 1 coat of Advance® Waterborne Interior Alkyd Primer (790) after removing plastic veneer by sanding away (an electric sander with a 100 grit

paper works fine; manual sanding may need to be vigorous)

Finish: 1 or more coats of Advance® Waterborne Interior Alkyd Satin (792)

Drvwall:

Primer: Advance® Waterborne Interior Alkyd Primer (790) or Fresh Start® Multi-Purpose Latex Primer (N023)

Finish: 1 or 2 coats Advance® Waterborne Interior Alkyd Satin (792)

Primer: Fresh Start® Multi-Purpose Latex Primer (N023) or Fresh Start® High-Hiding All Purpose Primer (046)

Finish: 1 or 2 coats Advance® Waterborne Interior Alkyd Satin (792)

Rough or Pitted Masonry: Primer: Ultra Spec® Masonry Interior/Exterior Hi-Build Block Filler (571)

Finish: 1 or 2 coats Advance® Waterborne Interior Alkyd Satin (792)

Smooth Poured or Pre-cast Concrete: Primer: Ultra Spec® Masonry Interior / Exterior 100% Acrylic Masonry Sealer

(608) or Fresh Start[®] Multi-Purpose Latex Primer (N023)

Finish: 1 or 2 coats Advance[®] Waterborne Interior Alkyd Satin (792)

Ferrous Metal (Steel and Iron):

Primer: Ultra Spec® HP Acrylic Metal Primer (HP04) or Super Spec HP® Alkyd

Metal Primer (P06)

Finish: 1 or 2 coats Advance® Waterborne Interior Alkyd Satin (792)

Non-Ferrous Metal (Galvanized & Aluminum):

All new metal surfaces must be thoroughly cleaned with Corotech® Oil & Grease Emulsifier (V600) to remove contaminants. New shiny non-ferrous metal surfaces that will be subject to abrasion should be dulled with very fine sandpaper or a synthetic steel wool pad to promote adhesion

Primer: Ultra Spec® HP Acrylic Metal Primer (HP04) Finish: 1 or 2 coats Advance® Waterborne Alkyd Satin (792)

Hard Glossy Alkyd Surfaces:

Abrasion by sanding required for optimum adhesion.

Repaint, All Substrates: Prime bare areas with the primer recommended for the substrate above. Sand glossy alkyds before applying Advance.

Application

Stir thoroughly before and during use. Apply one or two coats.

Paint Application: For best results, use a premium Benjamin Moore® custom-blended nylon/polyester brush, premium Benjamin Moore® Microfiber roller, or a similar product. Apply paint generously from unpainted area into wet area. This product can also be sprayed.

| Extra ventilation is necessary under humid conditions to speed the dry time of Advance, especially when the paint is applied over sealed, hard, non-porous surfaces. The chart below is for general guidance. | | | | |
|---|--|---------------------------------------|--|--|
| Mild conditions | Severe conditions | Very severe conditions | | |
| Dry (RH<50%), and Temperature between 70° F and 90° F | (RH> 50%), and/or temperature between 50° F and 70° F | RH> 85%, or temperature < 50° F | | |
| Advance will dry normally. Dry to touch: 4-6 hours To Recoat: 16 hours | Advance will dry slower than normal unless the following is done to speed the dry time: Ventilate the room with a fan and/or turn on A/C to lower the humidity. | Do not apply Advance | | |

Spray, Airless: Fluid Pressure — 1,500 - 2,500 PSI;

Tip - .011 - .015 Orifice

Spray, HVLP: Fluid Pressure — 20 PSI;

Tip — 1.8

Thinning/Clean Up

Thinning is unnecessary, but if required to obtain desired application properties, a small amount of clean water may be added. Never add other paints or solvents. Clean up with warm soapy water. Brushes and rollers should be given a final rinse with mineral spirits to remove residual alkyd. Spray equipment should be given a final rinse with mineral spirits to prevent rusting. Follow state/local guidelines on solvent use.

USE COMPLETELY OR DISPOSE OF PROPERLY. Dry, empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or statedesignated environmental agency on disposal options.

Environmental Health & Safety Information

Use only with adequate ventilation. Do not breathe spray mist or sanding dust. Ensure fresh air entry during application and drying. Avoid contact with eyes and prolonged or repeated contact with skin. May cause allergic skin reaction. Avoid exposure to dust and spray mist by wearing a NIOSH approved respirator during application, sanding and clean up. Follow respirator manufacturer's directions for respirator use. Close container after each use. Wash thoroughly after handling.



WARNING Cancer and Reproductive Harm-

www.P65warnings.ca.gov

FIRST AID: In case of eye contact, flush immediately with plenty of water for at least 15 minutes; for skin, wash thoroughly with soap and water. If symptoms persist, seek medical attention. If you experience difficulty breathing, leave the area to obtain fresh air. If continued difficulty is experienced, get medical attention immediately.

IN CASE OF SPILL - Absorb with inert material and dispose of as specified under "Clean Up"

KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING

Refer to Safety Data Sheet for additional health and safety information.