

Features

- · Latex Eggshell Paint
- · Fast Drying
- Low Sheen
- Low Odour
- Washable

General Description

930 LINE

Super Kote[™] 3000 Latex Enamel Eggshell is designed particularly for the professional contractor. The formulation provides that necessary balance between performance and value. Super Kote[™] 3000 Latex Enamel Eggshell demonstrates good hide and will withstand repeated washing without damaging the film. May be used for new work or re-do, commercial or residential applications.

SUPER KOTE[™] 3000

LATEX ENAMEL EGGSHELL

Recommended For

Professional-grade paint for commercial and residential use on drywall, plaster, wood, metal and masonry. Provides excellent touch up and hides imperfections in new construction and repaint work.

Limitations

 Apply only when surface and air temperatures are above 10 °C (50 °F).

on		
Technical Data◊		White
Vehicle Type		Latex
Pigment Type		Titanium Dioxide
Volume Solids		29.2 ± 1.0%
		27.9 – 37.2 sq. m. (300 – 400 sq. ft.)
Recommended Film Thickness	- Wet - Dry	4.0 to 5.3 mils 1.2 to 1.6 mils
Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure colour uniformity and minimize the disposal of excess paint.		
Dry Time @ 25 °C (77 °F) @ 50% RH	– Tack Free– To Recoat	30 minutes 4 hours
		s will result in longer
Dries By		Evaporation
Viscosity		92 – 97 KU
Flash Point		N/A
Gloss / Sheen	E	Eggshell 15 - 20 units @ 29.4 °C (85 °F)
Surface Temperature	– Min.	10 °C (50 °F)
at Application	– Max.	32.2 °C (90 °F)
Thin With		Clean Water
Clean Up Thinner		Warm, Soapy Water
Weight Per 3.79 L		4.9 kg (10.8 lbs)
Storage Temperature	– Min.	4.4 °C (40 °F)
	– Max.	35 °C (95 °F)
Volatile Organic O		nds (VOC)
29 Grams/Litre	e 0.11 kg (0.24 Lbs.)/3.79 L	
	Vehicle Type Pigment Type Volume Solids Coverage per 3.79 L a Recommended Film T Recommended Film T hickness Depending on surface estimate the right am ensure colour uniform excess paint. Dry Time @ 25 °C (77 °F) @ 50% RH High humidity and cod dry, recoat and service Dries By Viscosity Flash Point Gloss / Sheen Surface Temperature at Application Thin With Clean Up Thinner Weight Per 3.79 L Storage Temperature	Vehicle Type Pigment Type Volume Solids Coverage per 3.79 L at Recommended Film Thickness Recommended Film — Wet Thickness — Dry Depending on surface texture and estimate the right amount of paint tensure colour uniformity and minimexcess paint. Dry Time @ 25 °C — Tack Free (77 °F) @ 50% RH — To Recoat High humidity and cool temperatures dry, recoat and service times. Dries By Viscosity Flash Point Gloss / Sheen Surface Temperature at Application — Min. — Max. Thin With Clean Up Thinner Weight Per 3.79 L Storage Temperature — Min. — Max. Volatile Organic Compound

[♦] Reported values are for White. Contact dealer for values of other bases or colours.

Super Kote™ 3000 Latex Enamel Eggshell 930 Line

Surface Preparation

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials and mildew. Remove any peeling or scaling paint, and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust. Spot prime before and after filling nail holes, cracks, and other surface imperfections.

New plaster or masonry surfaces must be allowed to cure (30 days) before applying base coat. Cured plaster should be hard, have a slight sheen and maximum pH of 10; soft, porous or powdery plaster indicates improper cure. Remove any powder or loose particles.

Primers: New surfaces should be fully primed. Previously painted surfaces should be primed or spot primed as necessary. There are a number of specialty primers available in our family of brands that can be used on difficult substrates such as bleeding woods, hard glossy surfaces, or other substrates where paint adhesion or stain blocking is a problem. Your dealer can recommend the right problem solving primer necessary to meet your needs.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ http://www.hc-sc.gc.ca/ewh-semt/contaminants/lead-plomb/asked questions-questions-posees-eng.php.

Application

Stir product with a circular, lifting motion before you begin to paint. Super Kote™ 3000 Latex Eggshell Enamel may be applied by brush, roller, pad or spray techniques, at a rate of application not to exceed 37.2 square metres per 3.79 litres (400 square feet per gallon). Surface texture and porosity will affect actual yield. For best brush application results, use a quality synthetic filament brush. For roller application use a 6.4 mm to 9.5 mm (½" to 3/8") nap cover for smooth surfaces, a 12.7 mm (½") nap cover for semirough surfaces, and a 19.1 mm (¾") nap cover for rough surfaces. May be reduced with clean water up to 15% for spray application.

Clean up

Clean up with warm, soapy water.

Environmental Health & Safety Information

Use only in a well ventilated area. Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after handling.

KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING

Refer to Safety Data Sheet for additional health and safety information.