



SUPER KOTE™ 5000

LATEX PRODUCTION BLOCK FILLER

FLAT 958 LINE

Features

- Latex block filler designed for the production speed needed by professional painters
- Minimizes tip clogging
- Ready to spray out of the can
- Low Odour
- Low VOC
- Soap & Water Clean-up

Recommended For

Use on interior or exterior cementitious substrates in commercial, residential and institutional applications. Designed for spraying, it can be brushed or rolled.

General Description

Super Kote™ 5000 Production Block Filler is designed specifically for application by airless spray, although it may also be applied by brush or roller. It is packaged at a sprayable viscosity and is formulated using raw materials selected to minimize tip clogging.

Limitations

- Do not apply when surface or ambient temperature is less than 10 °C (50 °F)
- Not recommended for below grade application or for use under Solvent Based Epoxy Coatings
- Not recommended for use in car washes

Product Information										
Colours — Standard: White (11)	Technical Data White									
— Tint Bases: N/A	Vehicle Type Vinyl Acrylic									
— Special Colours: Contact your dealer.	Pigment Type Titanium Dioxide									
Certifications & Qualifications: VOC compliant in all regulated areas Qualifies for LEED® v4 Credit Qualifies for CHPS low emitting credit (Collaborative for High Performance Schools) CDPH v1 Emission Certified Master Painters Institute MPI # 4 and 4 X-Green™	Volume Solids 50 ± 1.0%									
Technical Assistance: Available through your local authorized independent dealer For the location of the dealer nearest you, call 1-866-708-9180 or visit www.coronadopaint.ca .	Coverage per 3.79 L at Recommended Film Thickness 7.0 – 9.3 sq. m. (75 – 100 sq. ft.)									
	<table border="0"> <tr> <td>Recommended Film Thickness</td> <td>– Wet</td> <td>16.0 to 21.4 mils</td> </tr> <tr> <td></td> <td>– Dry</td> <td>7.9 to 10.5 mils</td> </tr> </table>	Recommended Film Thickness	– Wet	16.0 to 21.4 mils		– Dry	7.9 to 10.5 mils			
Recommended Film Thickness	– Wet	16.0 to 21.4 mils								
	– Dry	7.9 to 10.5 mils								
	Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure colour uniformity and minimize the disposal of excess paint.									
	<table border="0"> <tr> <td>Dry Time @ 25 °C (77 °F) @ 50% RH</td> <td>– Tack Free</td> <td>30 Minutes</td> </tr> <tr> <td></td> <td>– To Recoat</td> <td>8 Hours</td> </tr> <tr> <td></td> <td>– Full Cure</td> <td>7 to 10 Days</td> </tr> </table>	Dry Time @ 25 °C (77 °F) @ 50% RH	– Tack Free	30 Minutes		– To Recoat	8 Hours		– Full Cure	7 to 10 Days
Dry Time @ 25 °C (77 °F) @ 50% RH	– Tack Free	30 Minutes								
	– To Recoat	8 Hours								
	– Full Cure	7 to 10 Days								
	High humidity and cool temperatures will result in longer dry, recoat and service times.									
	Dries By Evaporation, Coalescence									
	Viscosity 110 – 115 KU									
	Flash Point 93.2 °C (200 °F) or greater (TT-P-141, Method 4293)									
	Gloss / Sheen Flat (0 – 1 @ 85°)									
	<table border="0"> <tr> <td>Surface Temperature at Application</td> <td>– Min.</td> <td>10 °C (50 °F)</td> </tr> <tr> <td></td> <td>– Max.</td> <td>32.2 °C (90 °F)</td> </tr> </table>	Surface Temperature at Application	– Min.	10 °C (50 °F)		– Max.	32.2 °C (90 °F)			
Surface Temperature at Application	– Min.	10 °C (50 °F)								
	– Max.	32.2 °C (90 °F)								
	Thin With Clean Water									
	Clean Up Thinner Warm, Soapy Water									
	Weight Per 3.79 L 6.4 kg (14.1 lbs)									
	<table border="0"> <tr> <td>Storage Temperature</td> <td>– Min.</td> <td>10 °C (50 °F)</td> </tr> <tr> <td></td> <td>– Max.</td> <td>32.2 °C (90 °F)</td> </tr> </table>	Storage Temperature	– Min.	10 °C (50 °F)		– Max.	32.2 °C (90 °F)			
Storage Temperature	– Min.	10 °C (50 °F)								
	– Max.	32.2 °C (90 °F)								
	<p style="text-align: center;">Volatile Organic Compounds (VOC)</p> <p style="text-align: center;">37 Grams/Litre 0.14 kg (0.31 Lbs.)/3.79 L</p>									

◇ Reported values are for White. Contact dealer for values of other bases or colours.

Super Kote™ 5000 Latex Production Block Filler Flat 958 Line

Surface Preparation

958-11 is a block filler for rough masonry only; the recommendations below are for various substrates. Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials and mildew. Remove any peeling or scaling paint, and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust. Spot prime before and after filling nail holes, cracks, and other surface imperfections.

New plaster or masonry surfaces must be allowed to cure (30 days) before applying base coat. Cured plaster should be hard, have a slight sheen and maximum pH of 10; soft, porous or powdery plaster indicates improper cure. Knife off any protrusions and prime plaster before and after applying patching compound. Remove any powder or loose particles.

Primers: New surfaces should be fully primed. Previously painted surfaces should be primed or spot primed as necessary. There are a number of specialty primers available in our family of brands that can be used on difficult substrates such as bleeding woods, hard glossy surfaces, or other substrates where paint adhesion or stain blocking is a problem. Your dealer can recommend the right problem solving primer necessary to meet your needs.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ <https://www.canada.ca/en/health-canada/services/environmental-workplace-health/environmental-contaminants/lead/lead-information-package-some-commonly-asked-questions-about-lead-human-health.html>

Primer/Finish Systems

NOTE: When filling extremely porous block, or block with large voids, a second coat may be necessary to achieve proper fill.

Application

Stir product with a circular lifting motion. Apply generously as it comes from the can. If spraying by airless, use a .031 – .035 tip. Care must be taken to ensure that large voids are filled during spray application. Back rolling is recommended for a more uniform fill. When rolling, use a synthetic nap cover with a nap proportioned to the texture and porosity of the surface being filled. Do not apply when surface or ambient temperature is less than 10 °C (50 °F). Block Filler may be thinned sparingly with clean water if required for spraying.

Clean Up

Clean up with warm, soapy water.

Environmental Health & Safety Information

Use only in a well ventilated area. Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after handling.

**KEEP OUT OF REACH OF CHILDREN
PROTECT FROM FREEZING**

**Refer to Safety Data Sheet for
additional health and safety information.**